

ACT Table Restore

Warning: Controller must support Table Memory prior to loading any settings.

Load Table into Controller:

1. Use only Continental approved USB drives.
2. Ensure that the program files are stored on the USB drive in a folder labeled: "EA_MemoryCopy\Recipe"
3. Install the USB thumb drive into the USB port provided on the side of the Control Panel. *USB drive should light up.*
4. From the Main Menu, hold down on the upper left corner of the screen.
5. Panel will change to System Screen. Press OK to continue.
6. From the System Main Menu, select Memory.
7. Then select the Restore option.
8. Select USB, then press Next to continue.
9. Select the Recipe option.
10. Press OK to load the Recipe.
11. A window will display the Restore progress.
12. Press OK once the Restore is complete.

After the system is restored, the screen will reboot and go through the standard initialization. Once the main Start Motor screen displays, it is safe to remove the USB thumb drive from the port. The controller has been updated and is ready for use.